## SAFETY INSTRUCTIONS

1. Do not use outdoors. 2. Equipment should be mounted securely in locations and at heights where it will not be readily subjected to tampering by unauthorized personnel. 3. Do not mount near gas or electric heaters. 4. Cap unused wires with enclosed wire nuts or other approved method. 5. Do not use this equipment for anything other than its intended use. 6. The use of accessory equipment not recommended by the manufacturer will void product listing and warranty and may cause an unsafe condition. 7. Use caution when servicing batteries. 8. Any service on this equipment should be performed by qualified personnel only. 9. Make sure wire terminations are secure and leads are properly tucked in appropriate wire channels. **CONSULT A QUALIFIED ELECTRICIAN BEFORE INSTALLING**

**Caution:**
Disconnect AC power before servicing and installation. All electrical connections must be in accordance with NEC/CEC or your local code.

## INSTRUCTIONS STEPS

**1.**
Insert connector into track as shown.

**2.**
Twist 90 degree until connector locks into place. If Adaptor does not turn easily, twist in opposite direction. Caution: Forcing the adaptor in the wrong way could cause damage.

**3.**
After assembly, ground conductor on the adaptor and ground conductor on the track should be on the same side for proper installation

**4.**
Plug in




## REMOVE ADAPTOR FROM TRACK

**1.**
Depress lock tab and twist 90 degree until connector is free from track

